

Vantage PRO2™ INSTALLATION DIAGRAM

Wireless Vantage Pro2™ System (Console with Integrated Sensor Suite)

This diagram shows an Integrated Sensor Suite wirelessly connected to a Vantage Pro2 console with the console located within a home and the Integrated Sensor Suite mounted outside. The transmission distance between an Integrated Sensor Suite and console is up to 1000' (300 m) line of sight, or up to 600' (180 m) through walls and other obstructions.

